


SeedStar XP & Active Down Force


The QS Reset (Quick Start Reset) is only used in Variable Rate Drive planters. It is used when starting out in a corner or from a stop in the field. When you initially lower the planter, it times six seconds automatically. In that six seconds, you need to be above 1mph for the motors to take over. If the six seconds times out, you can hit the QS Reset to reset the time.

When selected, the “Rotate Seed Meters” button will rotate the meters approximately 1/2 of a revolution. Use this option to fill seed disks if vacs have been shut off.



These two arrows will manually shut off sections on your planter. If you have an area that you do not want planted and do not have a boundary you can use these to shut that section off.

The “Left” arrow works left to right and the “Right” arrow works right to left.



Use these scroll arrows to change the options that you want displayed.

